

118風潮開關 + 插座系列

118 TYPE TRENDY SERIES

- 延續傳統按壓手感，開關關閉時側面呈現完美弧度，就像停在海洋中的風帆



TLS051

風潮一開關
Sole Switch



TLS052

風潮二開關
Dual Switches



TLS053

風潮三開關
Trio Switches



TLS054

風潮四開關
Four Switches



TLS055

風潮五開關
Five Switches



TLS056

風潮六開關
Six Switches



TLS1525

風潮一開關一單插座附接地
Sole Switch With Ground Socket



TLS1511

風潮一開關二單插座附接地
Sole Switch With Dual Sockets



TLS1551

風潮二開關一單插座附接地
Dual Switches With Sockets



TLS4516

風潮雙聯一開關一雙插座附接地
Sole Switch with Sockets set



TLS4546

風潮雙聯二開一體開關一雙插座附接地
Dual Switches one modular With Sockets set




TLS4556

風潮雙聯三開一體開關一雙插座附接地
Trio Switches one modular With Sockets set

+ 118興富開關&插座系列

- 連續按壓手感，隨手開燈，隨手關燈
- 彈力手控，首創開關與面板平行更服貼牆面
- 一體成形，施工省時，事半功倍，外觀精美，底座穩固，零件穩定扎實

118 TYPE WEALTHY SERIES



TSS031

興富一開關
Sole Switch



TSS034

興富二開一體開關
Dual Switches



TSS035

興富三開一體開關
Trio Switches



TSS4434

興富四開關
Four Switches



TSS4445

興富五開關
Five Switches



TSS4435

興富六開關
Six Switches



TSS1325

興富一開關一單插座附接地
Sole Switch With Ground Socket



TSS041

興富四路一開關
Four Ways Switch



TSS1242

興富一四路一開關
Four Ways Switch with Sole Switch



TSS1311

興富一開關二單插座附接地
Sole Switch With Dual Sockets



TSS1331

興富雙聯二開一體開關二單插座附接地
Dual Switches one modular With Dual Sockets



TSS4316

興富雙聯一開關一雙插座附接地
Sole Switch with Sockets set



TSS4416

興富雙聯四路一開關一雙插座附接地
Four Ways Switch With Sockets set



TSS4346

興富雙聯二開一體開關一雙插座附接地
Dual Switches one modular With Sockets set



TSS4356


興富雙聯三開一體開關一雙插座附接地
Trio Switches one modular With Sockets set

RESTURANT
餐廳



實際案例

GOVERNMENT
PROJECT
公共工程



實際案例

RESIDENTIAL
住宅



實際案例

OFFICE
辦公空間



實際案例

HOTEL
飯店

+118插座 & 弱電系列

■ 118 TYPE PLUG SERIES TYPE



TGC141

萬用單插座
Sole Universal Socket



TGC142

萬用雙插座
Dual Universal Sockets



TGC115

單插座附接地
Sole Earthing Socket



TGC116

雙插座附接地
Dual Earthing Sockets



TGC115E

緊急單插座附接地
Emergency Sole Earthing Socket



TGC116E

緊急雙插座附接地
Emergency Dual Earthing Sockets



TGC117

節能雙插座附接地
Energy Saving Dual Earthing Sockets



TGC118

20A節能雙插座附接地
Energy Saving Dual Earthing Sockets 20A



TGC119

雙插座附接地(附LED)
LED Dual Earthing Sockets



TGC120

20A雙插座附接地
Dual Ground Sockets 20A



TGC021

冷氣插座
Sole T-Type Socket



TGC0A0

USB充電插座
Sole USB Socket



TGC1A05

—USB—單插座附接地
USB Socket With Ground Socket



TGC0U21

連體雙USB充電插座—單插座附接地
USB Sockets set With Ground Socket



TGC0A1 / TGC0A1R

電視插座(末端) / (中繼)
TV Socket



TGC0A2

電話單插座
Tel Socket



TGC0A3 / TGC0A8

網路單插座 (Cat.6) / (Cat.5)
Data Socket



TGC1A21 / TGC1A21R

—電話插座—電視插座 (末端)/(中繼)
Tel Socket With TV SocketSet



TGC1A22

二電話插座
Dual Tel Sockets



TGC1A23

—電話—網路插座
Tel Socket With Data Socket Set



TGC1A31 / TGC1A31R

—網路插座—電視插座 (末端)/(中繼)
Data Socket With TV Socket Set



TGC0C1

電鈴押扣
Doorbell Socket



TGC0C2-S
直式緊急開關(無段)
Stright Emergency Button
(Regained Type)



TGC0C2-H
橫式緊急開關(無段)
Horizontal Emergency Button
(Regained Type)



TGC0C2-SS
直式緊急開關(二段)
Stright Emergency Button
(Irreversible Type)



TGC0C2-HH
橫式緊急開關(二段)
Horizontal Emergency Button
(Irreversible Type)

新品即將推出
COMING SOON



TGCL118
漏電保護插座
Leakage Protection Socket



TGC1C0
118節能開關(含卡片)
118 Type Energy Saving Key Card Switch



TGC2C0K
節能開關卡片
Key Card